



PowerSwap Nucleus[®] Classic Lithium Power System



LEARN MORE AT
NEWCASTLESYS.COM/POWERSWAP-NUCLEUS



SAVE STEPS.
INCREASE PRODUCTIVITY.™

PowerSwap Nucleus Classic Power System Owner's Manual

Document Number: PowerSwap_Nucleus_00_H
Revision Date: May 5, 2023

Release Date: January, 2019

COPYRIGHT

All copyrights to this document are owned by Newcastle Systems, Inc. No part of the contents of this document may be reproduced or transmitted in any form or by any means without the prior written consent of Newcastle Systems, Inc.

NOTICE

Newcastle Systems, Inc. shall not be liable for errors contained herein. Newcastle Systems, Inc. shall not be liable for any damages whatsoever, including, without limitation, damages for loss of business profits, business interruption, loss of business information, or other pecuniary loss arising out of the use of this documentation even if Newcastle Systems, Inc. has been made aware of the possibility of such damages.

Information contained in this document is subject to change without notice. While every effort is made to ensure that the information is accurate as of the publication date, users are reminded to update their use of this document with documents published by Newcastle Systems, Inc. subsequent to this date. Updates may be available at www.newcastlesys.com or by contacting Newcastle Systems, Inc.

Copyright © 2023 by Newcastle Systems, Inc.
ALL RIGHTS RESERVED
Printed in U.S.A.

Newcastle Systems, Inc.
34 South Hunt Road
Amesbury, MA 01913

+1 (781) 935-3450
www.newcastlesys.com

Table of Contents

Important

Read and Understand this Manual Before Operation!.....	v
--------------------------------------------------------	---

System Components

Cart Configurations.....	1
PowerDock Station, PowerCharge Station and Battery	2

Operating Guidelines

Storage and Disposal.....	3
PowerDock (PWD2C & PWD2C-TSW) Operating Instructions.....	3
PowerCharge Operating Instructions	4
PowerDock Hybrid (PWD2-H-TSW) Operating Instructions	5
PowerDock Hybrid (PWD2-H-TSW) Charging Instructions.....	5

Preventative Maintenance

Maintenance.....	7
Inspection	7

Service/Warnings

Service.....	8
Warnings.....	8
Caution.....	8
Warnings/Precautions.....	9

Specifications

Battery Specifications.....	11
PowerDock Specifications.....	11
PowerCharge Specifications	12
PowerDock Hybrid Specifications	12
Operating, Transportation, and Storage Environment	12
Air Transportation Regulation.....	13

Important



Read and Understand this Manual Before Operation!

The Nucleus battery is specifically designed and optimized for the PowerDock and PowerCharge. Do not attempt to use a charger not manufactured by Newcastle Systems, Inc. with this product.

Special precautions and handling instructions are contained in this manual and should be strictly adhered to for safe and reliable operation. Contact Newcastle Systems, Inc. Customer Service at +1 (781) 935-3450 or customerservice@newcastlesys.com with any questions regarding this product.

System Components

Cart Configurations

PowerDock Station will be mounted to your selected cart configuration as shown below.



NB Series Cart



NB Series SLIM Cart



PC Series Cart & Atlas Series Cart



Apex Series Cart

PowerDock Station, PowerCharge Station and Battery



1. PowerDock Station (PWD2C, PWD2Ci or PWD2C-TSW): This will be installed on your Newcastle cart and provides AC power. See “[Cart Configurations](#)” on [page 1](#) to view your cart configuration.
2. PowerCharge Station (PWC2C or PWC2Ci): This is used to charge lithium batteries. It is stationary and plugs into a wall outlet.
3. PowerDock Hybrid Dock+Charge Station (PWD2-H-TSW): This will be optionally installed on your Newcastle cart. It provides AC power and can also be plugged into a wall outlet to charge batteries.
4. 36 AH/460 WH lithium iron phosphate battery (PSNU3.6): 1 to 4 units, based on your order.

Make sure batteries are fully charged prior to powering equipment.

Operating Guidelines

Storage and Disposal

Storage Instructions:

- DO NOT SHORT TERMINALS.
- This battery should be stored in a cool, dry, and well-ventilated area. Sustained elevated temperatures are the primary reason for premature failure of batteries. Charge batteries at room temperature. In warm climates, keep chargers in air conditioned rooms for best performance.
- Although our batteries have good self-discharge characteristics, batteries should be stored for long term storage in a fully charged condition.
- It is always a good idea to submit the battery to a discharge/charge cycle from time to time during storage.
- Do not store batteries in temperatures above 140° F/60° C or below -40° F/-20° C. Do not store in direct sunlight or near heating equipment.

Disposal Instructions:

- DO NOT INCINERATE. DO NOT DISASSEMBLE.
- Disposal must be in compliance with applicable regulations which vary depending on national, state/provincial and local basis. This battery contains recyclable materials so recycling is strongly recommended.

PowerDock (PWD2C & PWD2C-TSW) Operating Instructions



Step 1: Confirm the cart's power strip is already plugged in. (Located on the rear side of PowerDock as shown).



Step 2: Place 1 or 2 fully charged batteries in PowerDock Station. Make sure you hear a click as the battery engages and the LED lights on the battery are lit. *Batteries should be inserted firmly, but never slammed into place.



Step 3: Turn PowerDock Station on (-) (switch located as shown). LED above switch should light green.

Step 4: Plug your equipment (printer, laptop, etc.) into the cart's integrated power strip. Confirm that your power strip is turned on.

Operating Tips:

When unit is not in use, turn the PowerDock OFF. Batteries will continue to drain if unit is left on.

The PWD2C is equipped with GFCI circuit protection. Should the unit ever not output power, ensure that the GFCI has not tripped. Do not insert anything conductive into the unit as there is a live receptacle adjacent to the Reset button.

Monitor battery status with the LED meter on battery. When batteries become low, alarm will sound and battery should be swapped with a fully charged one.

PowerCharge Operating Instructions

Step 1: Connect the charge cord to the rear of the ChargeDock and the male plug to the wall.

Step 2: Place 1 or 2 discharged batteries in PowerCharge Station. Make sure you hear a click as the battery engages. *Batteries should be inserted firmly, but never slammed into place.

Step 3: Turn unit ON ("I" position as shown). ON/OFF switch is located at rear of unit as shown below.



Charging time of the PWC2C takes approximately 4-5 hours to charge fully depleted batteries.

Replaceable AC Fuse: This is located adjacent to the AC inlet of the PowerCharge to protect from overload. If fuse blows, replace with equivalent, fast-acting, 250 V, 6.3 A rated 5 mm x 20 mm glass fuse. **CAUTION:** installing non-rated fuses could cause equipment damage and void your warranty.

PowerDock Hybrid (PWD2-H-TSW) Operating Instructions

Male plug connects to wall for charging. Female receptacle connects to powerstrip. Equipment may be used while charging and charger may be left connected indefinitely.



Step 1: Confirm the cart's power strip is already plugged in.



Step 2: Place 1 or 2 fully charged batteries in PowerDock Station. Make sure you hear a click as the battery engages and the LED lights on the battery are lit. *Batteries should be inserted firmly, but never slammed into place.



Step 3: Turn PowerDock Station on (-) (switch located as shown).

Step 4: Plug your equipment (printer, laptop, etc.) into the cart's integrated power strip. Confirm that your power strip is turned on.

Operating Tips:

When unit is not in use, turn the PowerDock Hybrid OFF. Batteries will continue to drain if unit is left on.

The PWD2-H-TSW is equipped with GFCI circuit protection. Should the unit ever not output power, ensure that the GFCI has not tripped. Do not insert anything conductive into the unit as there is a live receptacle adjacent to the Reset button.

Monitor battery status with the LED meter on battery. When batteries become low, alarm will sound and battery should be charged or swapped.

PowerDock Hybrid (PWD2-H-TSW) Charging Instructions

Step 1: Place 1 or 2 discharged batteries in PowerDock Hybrid Station. Make sure you hear a click as the battery engages. *Batteries should be inserted firmly, but never slammed into place.

Step 2: Connect the 8' cord with male plug to the wall.

Charging time of the PWD2-H-TSW takes approximately 4-5 hours to charge fully depleted batteries.

Fuel Gauge

The following graphics illustrate the amount of battery power and corresponding LED lighting sequence.

Illustration of Fuel Gauge	LEDs	Battery Fuel
	5	81-100%
	4	61-80%
	3	41-60%
	2	21-40%
	1 solid	11-20%
	1 flashing	1-10%

Preventative Maintenance

Damaged connectors, contacts and cables may present hazards, resulting in inefficient battery and charger operation. To avoid these problems, conduct the following maintenance checks at least once annually. If you see any of the following problems, take corrective action immediately.

Maintenance

When engaged and disengaged, the contact surfaces of Nucleus connectors “over wipe,” thus providing a self cleaning action. To ensure the continued benefit of this feature, clean the contact surfaces with a cotton swab and lubricate the connector. Use a “white” lithium grease, which may be obtained from hardware stores and automotive parts suppliers.

Inspection

Check contact surfaces for signs of “pitting” caused by dirt or disengaging connectors under load. One badly pitted contact, particularly in a connector attached to a battery charger, can lead to pitting on surfaces of other contacts. If not corrected, this can result in an epidemic of bad connectors throughout a fleet of docks, chargers and batteries.

Service/Warnings

Service

In the event the Nucleus battery fails to deliver acceptable performance, it must be returned to Newcastle Systems, Inc. No other facility is qualified and equipped to service the Nucleus battery and calibrate the electronic components and sensors. Any attempt by the user or any other unauthorized persons may result in improper calibration of the electronic components causing severe battery damage and/or safety hazards, including potential personal injury and/or damage to property. Any such attempt will void any/all warranties.

Warnings

1. NEVER attempt to service this battery. If there is a problem, send this battery only to Newcastle Systems, Inc. for evaluation.
2. NEVER attempt to open this battery. The electronic circuits inside the battery can be damaged, causing malfunction and/or potential hazard to person and property.
3. NEVER attempt to replace the cells in this battery - it cannot be rebuilt or refurbished. At the end of its useful life, contact Newcastle Systems, Inc. Customer Service at +1 (781) 935-3450 or customerservice@newcastlesys.com.

Caution

1. Do not expose this battery to extreme high (above 140° F /60° C) or low (below 32° F/ 0° C) temperatures. This includes storage in direct sunlight, in cars in hot or cold weather, or in close proximity to heating/cooling devices. This may cause electrolyte leakage, impaired performance and shortening of battery service life.
2. When not using the battery for prolonged periods, the Nucleus battery should be fully charged.
3. ALL BATTERIES have a finite life. If the battery exhibits noticeably shortened run-time, the battery should be replaced immediately. Shortened run-time is indicative of at least one cell which has reached end of life. UNDER NO CIRCUMSTANCES should one attempt to “recondition” this battery by repeated charging and discharging.
4. This battery contains specialized electronic circuits, which are designed to protect the cells from overcharge, over discharge and over current. Redundant protection devices are designed to operate if the battery voltage is abnormally high or low and if the temperature of the battery exceeds operating specifications. These electronic devices can be damaged if the battery is subject to abuse or damage. Do not use a battery that has been subjected to excessive mechanical shock or water damage.
5. Do not drop, puncture or crush this battery. Do not use the battery if the case is damaged or broken. Do not open or attempt to service this battery if damaged.

Warnings/Precautions

1. Do not open to reduce the risk of fire or electric shock. There are no serviceable parts inside. Refer to qualified service personnel.
2. To reduce risk of electric shock, unplug the PowerCharge from the wall and unplug the DC input (battery) from the PowerDock before attempting any maintenance or cleaning.
3. To reduce risk of damage to electric plug and cord, pull by plug rather than cord when disconnecting anything from the unit.
4. An extension cord should not be used unless absolutely necessary.
5. Place the unit in an area that will allow air to flow freely around the unit. DO NOT block or obstruct vent openings or install the unit in an enclosed compartment.
6. Keep the unit away from moisture and water.
7. Never operate two or more units in parallel.
8. To avoid risk of electric shock, this equipment must only be connected to a supply mains with protective ground.

EU Waste Electrical and Electronic Equipment (WEEE) Directive



Figure 1: WEEE symbol – crossed out wheeled bin

For private households: Information on Disposal for Users of WEEE:

This symbol (Figure 1) on the product(s) and/or accompanying documents means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge.

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

Please contact your local authority for further details of your nearest designated collection point.

Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

For professional users in the European Union:

If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information.

For disposal in countries outside of the European Union:

This symbol is only valid in the European Union (EU). If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.

ENVIRONMENTAL HAZARD


Contains Lithium-Ion.





Disposal: DO NOT dispose of the Nucleus components and its associated components and/or accessories in municipal waste at the end of their expected service life. Consult Newcastle Systems, Inc. Customer Service for information on disposal/recycling of the Nucleus battery interface and its associated components and/or accessories.

Specifications



Battery Specifications

Voltage	12.8 V Nominal 10.0 V - 14.6 V Operating		
Capacity	36 Ah		
Chemistry	Lithium Iron Phosphate (LiFePO ₄)		
Maximum Discharge Rate	12.0 A per battery		
Cut-off Charge Current	2000 mA		
Typical Run-Time (Assuming Constant Load)		1 Battery	2 Batteries
	@ 18W	20 hrs	40 hrs
	@ 45W	8 hrs	16 hrs
	@ 72W	5 hrs	10 hrs
	@ 120W	3 hrs	6 hrs
Weight	11 lbs (5 kg)		
Size	12.8" (326 mm) L x 6.5" (165 mm) W x 6.4" (163 mm) H		
Regulatory Approvals			

PowerDock Specifications

	PWD2C	PWD2Ci	PWD2C-TSW
Output Voltage	120 VAC ± 3% Modified Sine Wave	120 VAC ± 3% True Sine Wave	230 VAC ± 3% True Sine Wave
Output Current	2.0 A	2.0 A	1.0 A
Output Frequency	60 Hz ± 1%	60 Hz ± 1%	50/60 Hz ± 1%
Regulatory Approvals			

PowerCharge Specifications

	PWC2C	PWC2Ci
Power Input	120 VAC 50-60 Hz 5.0 A	230 VAC 50-60 Hz 2.8 A
Charge Current	9.0 A	9.0 A
Charge Time	4-5 hrs	4-5 hrs
Regulatory Approvals		

PowerDock Hybrid Specifications

	PWD2C-H-TSW
Power Input	120 VAC 50-60 Hz 4.8 A
Charge Current	9.0 A
Charge Time	4-5 hrs
Output Voltage	120 VAC \pm 3%, True Sine Wave
Output Current	2.0 A
Output Frequency	60 Hz \pm 1%

Operating, Transportation, and Storage Environment

Discharge Temperature Range	32-104° F (0-40° C)
Charge Temperature Range	32-95° F (0-35° C)
Storage Temperature Range	-40 to 140° F (-20 to 60° C)
Relative Humidity	20-70% non-condensing
Pressure	985 hPa to 1040 hPa
Device intended for indoor use only.	
Never use flammable or combustible solvents around batteries or chargers.	

Air Transportation Regulation

Air Transportation Regulation

Dangerous Goods Regulations 49CFR Parts 100-185, Air Transport Association (IATA) and the International Civil Aviation Organization (ICAO) regulations apply to all Lithium-Ion battery transport.

Air Transportation Declaration

Newcastle Systems, Inc. declares that the Nucleus Lithium-Ion battery pack contains equivalent lithium content (ELC) in a quantity exceeding 8 grams and less than 25 grams and therefore is considered and must be handled and transported as a class 9 Hazardous article and is subject to regulation under Dangerous Good Regulations.

49 CFR Parts 100-185

Since the interpretation and application of regulations may vary with the aviation company, the transport of the Nucleus battery may be disallowed even when the condition described above are satisfied. Newcastle Systems, Inc. therefore strongly recommends that you consult with your transportation company prior to transporting the battery pack.

OWNER'S MANUAL



34 South Hunt Road
Amesbury, MA 01913 / USA
+1.781.935.3450
www.newcastlesys.com



**SAVE STEPS.
INCREASE PRODUCTIVITY.™**